

**SONIFEX**

Mentor Time-Server

# Catalogue



## Mentor Time-Server

The Mentor Time Server is software which runs on a MS-Windows Windows™ 7/8/10 PC and synchronizes a number of MS-Windows Windows™ 7/8/10 PC client machines or Sonifex Net-Log units to its time. The client PCs or Net-Logs read the server time and have their time set using TCP/IP at regular intervals.

### Clock Sources

Mentor Server can be synchronised to NTP (Time servers on the Internet).

For pricing information, please contact the Sales Department.

### Sonifex Mentor Client Installation

The Mentor Client software can be installed on any number of PCs connected to network where a Mentor Server is located, but clock updates will only be performed up to the number of client licences installed on the server.

### Mentor Server

The Mentor Server to connect to is identified by its TCP/IP address.

### Equipment Type Mentor

MTS-5	Mentor Time-Server 5 client licence
MTS-25	Mentor Time-Server 25 client licence
MTS-100	Mentor Time-Server 100 client licence
MTS-500	Mentor Time-Server 500 client licence

# **SONIFEX**

[www.sonifex.co.uk](http://www.sonifex.co.uk)

---

## **UK Office:**

### **Sonifex Ltd**

61 Station Road, Irthlingborough,

Northants, NN9 5QE, UK

Tel: +44 (0) 1933 650700

Fax: +44 (0) 1933 650726

Email: [sales@sonifex.co.uk](mailto:sales@sonifex.co.uk)

## **Australian Office:**

### **Sonifex Pty Ltd**

12/6 Leighton Place,

Hornsby NSW 2077, Australia

Tel: +61 (2) 9987 0499

Fax: +61 (2) 9476 4950

Email: [sales@sonifex.com.au](mailto:sales@sonifex.com.au)