

SONIFEX

Mentor Time-Server

Catalogue ²⁰¹⁶



Mentor Time-Server

The Mentor Time Server is software which runs on a MS-Windows Windows™ 7/8/10 PC and synchronizes a number of MS-Windows Windows™ 7/8/10 PC client machines or Sonifex Net-Log units to its time. The client PCs or Net-Logs read the server time and have their time set using TCP/IP at regular intervals.

Clock Sources

Mentor Server can be synchronised to NTP (Time servers on the Internet).

For pricing information, please contact the Sales Department.

Sonifex Mentor Client Installation

The Mentor Client software can be installed on any number of PCs connected to network where a Mentor Server is located, but clock updates will only be performed up to the number of client licences installed on the server.

Mentor Server

The Mentor Server to connect to is identified by its TCP/IP address.

Equipment Type Mentor

MTS-5	Mentor Time-Server 5 client licence
MTS-25	Mentor Time-Server 25 client licence
MTS-100	Mentor Time-Server 100 client licence
MTS-500	Mentor Time-Server 500 client licence

SONIFEX

www.sonifex.co.uk

UK Office:

Sonifex Ltd

61 Station Road, Irthlingborough,

Northants, NN9 5QE, UK

Tel: +44 (0) 1933 650700

Fax: +44 (0) 1933 650726

Email: sales@sonifex.co.uk

Australian Office:

Sonifex Pty Ltd

12/6 Leighton Place,

Hornsby NSW 2077, Australia

Tel: +61 (2) 9987 0499

Fax: +61 (2) 9476 4950

Email: sales@sonifex.com.au