

FM Radcap Linux Driver

sysfs Interface

sys/bus/pci/drivers/FMRADCAPPCIE/0000:03:00.0¹

band	AM or FM (read-only)
deemphasis	50 or 75 (card-specific override)
hardware_id	Unique card identifier (read-only)
num_stations	Number of stations on the card (read-only)

sys/bus/pci/drivers/FMRADCAPPCIE/0000:03:00.0¹/StationNN²

ForceMono	0 (automatic) or 1 (always mono)
Frequency	Station frequency in kHz
NarrowAudio	0 (full bandwidth) or 1 (narrow bandwidth)
RSSI	Received signal strength indicator (read-only)
Stereo	Stereo reception indicator (read-only)

¹ This identifies the individual card and will vary on different systems

² NN ranges from 00 to one less than the number of stations